



# Instructions for Painless switch part numbers 80400, 80401, 80402, 80403, 80404, & 80405


## MOMENTARY ON SWITCH



## ON-OFF SWITCH



## ON-OFF-ON SWITCH



**DIODE INSTALLATION:** With diode stripe on top (as shown) it will send power out the bottom and top output wires when the top of the switch is pushed, but it will only send power out the top output wire when the bottom side of the switch is pushed. It will be opposite if the diode is reversed.

**PAINLESS**  
**PERFORMANCE PRODUCTS**