

to "START/CHARGE" section

COLUMN MOUNTED GM IGNITION SWITCH

STARTER "S" TERMINAL #919 IGNITION SWITCH "START"

#934 TO IGNITION SWITCH POWER B+

#934 TO IGNITION SWITCH POWER B+

#933 TO IGNITION SWITCH "IGN" TERMINAL

#932 TO IGNITION SWITCH ACCESSORY TERMINAL

#931 TO IGNITION SWITCH (COIL)

● = SPLICE

PAINLESS
PERFORMANCE PRODUCTS®

